



CONTROLLED ROOM TEMPERATURE (CRT) CABINETS

FOR STORAGE OF PHARMACY PRODUCTS AT 15°C -25°C

ROOM TEMPERATURE STORAGE

The World Health Organisation have defined 'room temperature' with regards to medicine storage as between 15°C and 25°C. Outside this temperature range the efficacy of drugs and medicines can be affected resulting in reduced shelf life and wastage. Air conditioning is expensive to install and run and is often turned off at evenings or weekends, or not an option at all due to building design or restrictions.

QED Scientific have developed a range of award winning CRT medicines cabinets specifically designed to store medicines between 15°C and 25°C in almost any room conditions.

Our range of standard CRT cabinets are of the same construction as a pharmacy refrigerator, but operate between 15°C and 25°C making them the perfect solution for clinical trials where proof of temperature storage conditions is imperative.

They do not meet BS2881:1989 for their construction, nor do they have BS3621 conforming locks.

They are an extremely cost effective way of providing room temperature (15°C to 25°C) conditions in rooms which cannot be controlled by air conditioning 24/7, so protecting the efficacy and shelf life of your valuable medicines.

Available in 10 capacities from 30 litres to 1390 litres with a choice of glass or solid doors in the models up to 500 litres and solid doors on the larger units, there is a model to suit every requirement.

Our larger, stainless steel models are able to be fitted with a small inner controlled drugs cabinet which, when fixed through the outer cabinet to a suitable wall with our provided fixings, meets all UK legislation for construction, security and storage of controlled drugs.

FEATURES

- Digital Display Controller
- Alarms for Minimum/ Maximum Temperature, power failure and door open
- Simulated core load temperature logger
- 5 year warranty
- Eco Friendly Refrigerants
- Door locks



Contact us to discuss your requirements and specification or to request further information.

Office

info@qedscientific.com

01663 735494

PHARMACY RANGE

Our complete range of temperature controlled pharmacy storage solutions are the ideal solution for pharmacies, care homes, clinical trials and indeed any area where there is a need to manage the temperature of medicines and drug storage to meet current legislation, maximise efficacy and preserve shelf life.

MED-CRT CABINETS

These wall mounted cupboards are an alternative to the freestanding CRT style cabinets. comply with BS2881 and have door locks which meet BS3621.

The cooling system correctly monitors, controls and maintains the temperature below 25°C in warm weather.

There are various sizes available and all must be bolted to a suitable wall.

Larger models can also be fitted with an inner cupboard for Controlled Drugs (MED-CRT/CD models).

CD-CRT CABINETS

Designed specifically to store Controlled Drugs below 25°C as required by BS2881:1989 and all Misuse of Drugs legislation and have BS3621 conforming anti-pick and drill locks.

The cooling system correctly monitors and maintains the temperature below 25°C.

There are 5 sizes available between 27 litres and 196 litres.

All must be wall mounted.

CD CABINETS

Our extensive range of controlled drugs cabinets are manufactured in the UK and all conform to BS2881: 1989 (Security Level One) and have BS3621 conforming locks.

This is the specification for Cupboards for the Storage of Medicines in Health Care Premises. Furthermore, meets or surpasses the requirements of the “Misuse of Drugs (Safe Custody) Regulations 1973”. This is the requirement in the UK for the storage of controlled drugs.

Available in a large range of capacities from 8.7 litres up to 400 litres and constructed from a minimum 1.5mm thick cold reduced mild steel sheet with 3mm thick anchor plates at all fixing points and a fully welded construction. All feature an Anti-Jimmy folded return down full length of hinge side of door.

ADVANCED PHARMACY FRIDGES

Designed to reliably store refrigerated medicines and vaccines. 10 fridge sizes from 30 litres to 1250 litres.

All QED pharmacy fridges have hard wearing metal chambers.

The 30 and 60 litre models can be bench or wall mounted.

Models up to 500 litres have a 5 year warranty and are available with solid or glazed doors.

Larger solid door models are heavy duty for bulk medicine storage.

All have a key lock that can be upgraded to digital keypad.

